
INTERIOR SURFACE PREP

Clean Dry & Dull!





• **Taped and Sanded Drywall**

- Remove all sanding dust
 - Prime with PVA Primer
 - Check surface for imperfections (small holes, dings)
 - Patch imperfections
 - Sand Patches
 - Reprime Patches
 - Paint
-



-
- **Previously Painted Walls**
 - **Flat and Eggshell Paint**
 - Wash any dirty, greasy areas, especially around light switches, outside corners
 - Patch all holes and dents
 - When dry, Sand all patches and touch ups with 1 coat of finish product
 - Paint



Previously Painted Walls

Satin, Semi-Gloss or Gloss Paint

- Wash walls with a solution of TSP and Warm Water using a Medium Grit foam sanding block
 - Especially areas of greater abuse and/or contamination (Bathrooms, Kitchens, Mudrooms, Hallways, etc.). This will clean, degrease and degloss.
 - Rinse with water
 - Patch all holes, nicks and dings with spackle
 - When dry, Sand patches
 - Prime walls with 1 coat of an appropriate Primer
 - Paint
-

Wood Doors & Trim

Bare Wood

- Fill all nail holes with appropriate putty or filler
- Prime with 1 coat of an appropriate primer
- Paint with Door and Trim Paint

Previously Painted/Finished or Laminated Surfaces

- Wash all areas with a solution of TSP and Warm Water using a Medium Grit Foam sanding block
 - Rinse with water
 - Prime all areas with 1 coat of an appropriate Primer
 - Finish with Door and trim paint or equivalent in selected finish
-

